



# Firestone

## SPECIALTY PRODUCTS

### **PondGard Installation Detail 12-**

#### Removing a "Fish Mouth" Gap From a Quickseam Cover Strip

	<p><b>Step 1-</b> Squeeze with your fingers or attempt to hand roll the "fish mouth" gap to the edge of the QuickSeam Cover Strip.</p>
	<p><b>Step 2-</b> If the gap forms a void all the way under the tape to the overlap's edge; tape over and beyond the void with a patch of QuickSeam Cover Strip.</p> <p><b>Notes:</b></p> <ol style="list-style-type: none"><li>1. Make sure to extend the tape a minimum of 3" on all sides.</li><li>2. Caulk if necessary.</li></ol>

#### **This Detail featured these Firestone Specialty Products:**

<u>Item</u>	<u>Part Number(s)</u>
• PondGard EPDM Rubber Membrane	Varies by Size
• QuickPrime Plus Primer	W563587041 or W563587044
• QuickScrubber	W563582045
• Hand roller	W563582023
• 6" QuickSeam Cover Strip tape	W56RAC1693 or W56RAC1616