



Assembly Instructions

The following instructions will assist you in assembling your particular fountain. Depending on which fountain you have purchased there will be slight variations in how they get assembled.



Pearl - Item # 03800



Aura - Item # 03801



Mantra - Item # 03850



Harmony - Item # 03821



Euphoria - Item # 03820



Halo - Item # 03802



Adore - Item # 03810



Felicity - Item # 03822




Fig. A



Fig. B



Fig. C




Fig. E




Fig. F

- STEP 1** SET THE "FLOW CONTROL" ON THE PUMP TO THE FULLY OPEN POSITION. DO THIS BY SLIDING THE STEM ON THE FRONT OF THE PUMP COVER ALL THE WAY OVER TO THE "+" SIGN. **(Fig A)**.
- STEP 2** ATTACH THE INCLUDED PLASTIC FITTING INTO THE PUMP OUTLET **(Fig. A)** (DEPENDENT ON YOUR MODEL, SOME FITTINGS MAY ALREADY BE PRE-INSTALLED AT THE FACTORY)
- STEP 3** INSERT THE L.E.D. INTO THE SHORTER PLASTIC TUBE COMING FROM THE BASE OF THE FOUNTAIN. PUSH IN UNTIL SNUG. **(Fig. B)** *For Pearl Fountain refer to step 3a.*
- STEP 3a** *(Pearl only)* SLIDE THE L.E.D. RING OVER THE SINGLE PLASTIC TUBE EXTENDING FROM THE BASE OF THE FOUNTAIN. PUSH ON UNTIL SNUG. **(Fig C)**
- STEP 4** ATTACH THE PUMP (with plastic fitting installed) TO THE LONGER PLASTIC TUBE EXTENDING FROM THE BASE OF THE FOUNTAIN. **(Fig D)**
- STEP 5** PLACE THE PUMP ONTO THE BASIN, MAKING SURE THAT THE BARREL CONNECTOR **(Fig. E)** REMAINS OUTSIDE THE BASIN. **(DO NOT SUBMERSE THE BARREL CONNECTOR IN WATER)**. NOW PLACE THE FOUNTAIN ON TOP OF THE BASIN. BE SURE THE BASIN IS SITTING ON A LEVEL SURFACE.
- STEP 6** PLUG THE MALE BARREL CONNECTOR FROM THE L.E.D. INTO THE MATING CONNECTOR COMING OUT OF THE PUMP. **(Fig E)** (DOES NOT APPLY TO MODELS THAT ARE PRE-WIRED). **BE SURE THIS CONNECTION REMAINS OUT OF THE WATER.** THE CONNECTION SHOULD BE VISIBLE AFTER THE FOUNTAIN HAS BEEN PLACED ONTO THE BASIN.
- STEP 7** PLUG THE MALE BARREL CONNECTOR FROM THE 6 FT LONG PUMP/L.E.D. CORD INTO THE RECEPTACLE ON THE INCLUDED A.C. WALL ADAPTER.
- STEP 8** FILL THE BASIN WITH WATER UNTIL IT TOUCHES THE BASE PLATE OF THE FOUNTAIN.
- STEP 9** ADD DECORATIVE ROCKS INCLUDED WITH FOUNTAIN TO TOP OF BASE PLATE.
- STEP 10** *(Pearl only)* INSTALL CRYSTAL BALL INTO CENTER CAVITY OF FOUNTAIN. **(Fig F)**
- STEP 11** PLUG A.C. WALL ADAPTER INTO OUTLET. BE SURE TO LEAVE A "DRIP LOOP" IN THE WIRE. **(SEE FIG. 1 ON NEXT PAGE)**

NOTES:


- 1) If water does not flow shortly after power up, unplug and refer to STEP 1 to confirm that the flow control is in the fully open position. **OR** Air may be trapped within the pump. Remedy this by removing the pump & placing back into the filled basin.
- 2) If splashing occurs when the fountain is running, try re-arranging the rocks **or** reduce the flow rate on the pump by sliding the stem on the front cover towards the other side.

Care and Operating Instructions

**SAVE THESE
INSTRUCTIONS**

WARNINGS:

- This product is for INDOOR use only.
- Pump must ALWAYS be submerged in water. DO NOT RUN DRY.
- Keep ALL electrical connections out of the water.
- Never plug into outlet if any part of the product appears to be damaged.
- Check for leaks after initial setup and occasionally afterwards.
- DO NOT use any household cleaners on any of the surfaces.
- ALWAYS use a “Drip Loop” when operating the pump (see Fig.1).



MAINTENANCE:

- Change water periodically to reduce scaling & mineral buildup.
- Check water level and add as necessary to maintain proper level.
- Drain all water from basin if fountain will be out of service for an extended period of time.
- Remove pump from fountain periodically and rinse with fresh water to remove any debris or buildup.
- Rinse basin periodically with tap water and wipe away any buildup.
- Use of distilled water will prevent mineral buildup.

Limited Warranty

E. G. Danner will repair or replace any unit found to be mechanically defective within 90 days of purchase. For warranty issues please contact Danner Customer Service for information before returning product. A dated proof of purchase must be presented to validate any warranty claim. Damages or injuries resulting from negligence, abuse or misuse of this product are excluded from this warranty. This warranty gives you specific legal rights and you may have other rights which vary from state to state.

ZG0380-Rev.B 01/20